



## Winkel-Adapter RSA-X80g-1 Angled Adapter RSA-X80g-1




## Adapter RSA-X80g-2




## Adapter RSA-5/8-1

mit 5/8" Gewinde  
with 5/8" thread




## Adapter RSA-H40


mit M8 Innen- und M5 Außengewinde  
with M8 female tread and M5 male thread




## Fixpunkt RSFP-X80 Fixed Point RSFP-X80




## Saugnapf RSSV-X80 Suction cup RSSV-X80



## Magnettopf RSMS1033 Magnet Pot RSMS1033



## Magnet RSM1030 Magnet RSM1030




## Magnet RSMS1062

## Magnet RSMS1062


für RSMP380 und RSMP480

for RSMP380 and RSMP480



## Schutzkappe RSPC20 + 20M

## Protection Cap RSPC20 + 20M




## Metallwürfel RSPC50

mit 5/8" Gewinde

## Metal Cube RSPC50



with 5/8" thread




## Adapter RSA-490M

für Dibond Produkte


for dibond products



**Muffen-Adapter RSA-K480**  
**Coupler Adapter RSA-K480**



**Muffen-Adapter RSA-K625**  
**Coupler Adapter RSA-K625**



**Muffen-Adapter RSA-K480**  
**Coupler Adapter RSA-K480**

